

Unpacking and Repacking 開梱・再梱包方法

⚠ CAUTION Unpacking, installation, and moving must be carried out by four or more persons.

Failure to do so may result in dropping the unit, leading to injury. (The total weight of the package is 178 kg (392.4 lb.) for the SJ-600, 163 kg (359.3 lb) for the SJ-500.)

⚠ 注意

開梱・設置・移動は4人以上で行ってください。
本体やスタンドが落下し、けがをすることがあります。(梱包総重量は、SJ-600:178 kg、SJ-500:163 kgです。)

* How to Unpack 開梱方法 *


The packings will be needed if you must repackage the product. Please do not throw them away.

梱包材は再梱包するときに必要ですので捨てないでください。




* For detailed information about unpacking, assembly, and installation, see the separate "User's Manual."
* 開梱、組み立て、設置に関する詳しい情報は、別冊の「ユーザーズマニュアル」をご覧ください。

1




2

Open the stand packing carton.
スタンド梱包箱を開ける




3

Open the accessories box.
付属品箱を開ける



4


Take out the unit.
本体を取り出す



5

Assemble the stand and the machine. For more information about how to assemble, see the separate "User's Manual."
スタンドと本体を組み立てます。組み立て方法については、別冊の「ユーザーズマニュアル」をご覧ください。

6



* How to Repack 再梱包方法 *

Please be sure to remove ink as described in the section "Maintenance -- When Moving the Unit..." in the user's manual. Then, repackage the machine in the reverse order of this procedure.

付属のユーザーズマニュアル「メンテナンス_移送するときは...」に従ってインクの抜き取りを行ってから、「開梱方法」と逆の手順で再梱包してください。